

# How to Fixed Installation



1.Cleaning glass with water jet

2.Tear off the film

3.Spray water on the form

4.Use a level to align the screen installation position

5.Use a scraper to gently remove water and bubbles.

6.The hub board should not be exposed to water. After attaching the glass, use a hair dryer to drv the hub board at low temperature.

7.After connecting all modules, wait 24 hours before installing the power supply.

8.After 24 hours, install the power box according to the following sequence of pictures

